


# Map Customisation User Guide

## 1. Background

If your navigation system has software version 4.4.0 or later, the pre-installed map will either be East Europe or West Europe. This user guide takes you through the required steps should you wish to customise ('configure') your map such that countries are added or deleted to suit your needs. The countries defined within 'East Europe' and 'West Europe' map are listed in Appendix A.

## 2. Check Software version

Whether or not you have a configurable map depends on the software version of your navigation device. To check the software version, please go to your navigation device and follow the steps below.



Select the 'General' button in the main Setup menu.



Selecting 'System Information' allows you see your device software version.



The software version is shown at the top of the screen as circled above.

If you have an older software version (version earlier than 4.4.0) then the map is not configurable. If you like, you can purchase a more recent map, which will also be configurable.


If you have a more recent software version (4.4.0 or later) then you already have a configurable map. In this case you can either download the full Europe map to USB, ready for the configuration process, or purchase a more recent map version if available.

Further information on software versions can be found in Appendix B.


### 3. Download Full Europe Map

The following section describes the steps needed to obtain the full Europe map. Once this map is downloaded, you will be able to customise the map to suit your needs.


Visit the e-Store showing the featured products.



Select 'Maps & Software Updates' tab.



Clicking on 'Map of Europe' displays the following product detail page.



Select your vehicle (if you have more than one device/vehicle registered) and enter your software version. Once this is verified, the system will make available for download the full map of Europe matching your software version. Pressing the 'Download' icon will download the file to your PC. You will need to unzip the downloaded file before copying to a USB stick.

**NOTE:**

The USB stick needs to be FAT 32 formatted, with a capacity of 8 GB or greater. The USB stick memory should be empty. To check if this is the case, or to get more details, insert the USB stick into your PC / laptop and right-click on the USB icon.

Please note that the software should be copied to the 'root' file structure of the USB stick, and not saved to any other directories or folders.

**Unzip** the downloaded content onto your USB stick. Verify that the following files/directories are in the root directory:

- nav (= directory)
- KaliSWDL.log
- swdl.iso
- swdl.iso.md5
- swdlInstall.iso
- swdlInstall.iso.md5

Once you have copied the map update content to your USB stick, you can start the map configuration process on your navigation device.

## 4. Configure your map

Insert the USB stick into your navigation device. The following screen will appear:



Entering 'Yes' to proceed will bring up the following screen, allowing you to select your region (East or West).



You can also select on a country-by-country basis using the 'Select by country' button.



Here you can choose your preferred countries, as well as checking how much system memory your selection uses ('Your percentage'). The estimated time to upload the changes to your device is also shown; in above example this is around 23 minutes.

Once you are satisfied with your selection, press the 'Update' button. This will take you to the following screens:



Press 'Confirm' will initiate the update and the system will cycle through the following two screens:



Once the update is completed, you are ready to make use of your new configured map. Please note that a single journey from East to West or vice versa is still possible as long as the countries along the route are available in your configured map.

## Appendix A

<b>WEST MAP</b>	
Albania	Latvia
Andorra	Liechtenstein
Austria	Lithuania
Belgium	Luxembourg
Bosnia & Herzegovina	Malta
Bulgaria	Monaco
Croatia	Montenegro
Czech Republic	Netherlands
Denmark	Norway
Estonia	Poland
Finland	Portugal
France	Romania
FYROM	San Marino
Germany	Serbia
Gibraltar	Slovakia
Greece	Slovenia
Hungary	Spain
Iceland	Sweden
Ireland	Switzerland
Italy	UK
Kosovo	Vatican

<b>EAST MAP</b>	
Albania	Kosovo
Austria	Latvia
Belarus	Lithuania
Bosnia & Herzegovina	Moldova
Bulgaria	Montenegro
Croatia	Poland
Czech Republic	Romania
Estonia	Russia
Finland	San Marino
FYROM	Serbia
Germany	Slovakia
Greece	Slovenia
Hungary	Turkey
Italy	Ukraine
Kazakhstan	Vatican

## Appendix B

List of software versions which support / do not support configurable map:

<b>Non-configurable Map</b>	<b>Configurable Map starts from</b>
3.3.0 L	4.4.0 L/H
4.2.1 L/H	
4.2.2 L/H	
4.3.0 L/H	
4.3.1 L/H	